



**MOUNTING INSTRUCTIONS FOR COOLING UNIT**

- 1) CHECK THE DIMENSIONS OF THE DRILLING TEMPLATE BEFORE DRILLING OR CUTTING.
- 2) STICK THE BORE TEMPLATE WITH ADHESIVE TAPE ONTO THE SIDE PANELS OR DOOR OF THE ENCLOSURE.
- 3) PUNCH, DRILL AND DEBURR HOLES.
- 4) CUT OUT AND DEBURR ALONG THE MARKING LINE OF THE APERTURES.
- 5) CUT THE SEALS TO LENGTH AND STICK IT ONTO THE REAR RISE OF THE UNIT.
- 6) ATTACH THE COOLING UNIT WITH SCREWS, WASHER AND NUTS WHICH ARE PROVIDED.